

Analog Remote UR5U-8700L and UR5U-8720L



Instructions

1. To program your remote to a new TV: **Auto-Search Method**

STEP 1: Turn on the Component you want to program (TV).

STEP 2: Press the [COMPONENT] button (TV) to be programmed and [OK/SEL] button simultaneously for 3 seconds. The Component LED light will turn on for 30 seconds indicating the unit is ready to be programmed.

STEP 3: Point the remote toward the Component and press the [CH+] or [CH-] button one step at a time or keep it pressed. The remote will emit a series of ON/OFF commands. Release the [CH+] or [CH-] button as soon as the TV turns Off.

STEP 4: Test functions. (Same as for 3-Digit Code Programming Method – Section A). If any of the functions do not work as they should, repeat from STEP 3 using [CH+] or [CH-] buttons to find the correct code.

STEP 5: Save the code. (Same as for 3-Digit Code Programming Method - Section A).

2. Then go to voice mail pop up time and select the left arrow until **"No Pop Up"** is displayed.

3. Select **Save**.

