

Parental Controls for Video On Demand

To setup Parental Controls for your Video On Demand, use your remote and follow the steps below for both set of instructions:

1. Menu
2. Settings
3. Parental
4. Options
5. Enter pin (default 0000)
6. Show locked channels - Select No
7. Show locked titles - Select No

1. Menu
2. Settings
3. Parental
4. Set ratings
5. Enter pin
6. TV rating – TV MA

When the block is completed the content will display as “Rated Content”